

# ABARTH 595 Front Grille

## INSTRUCTIONS

Step 1. Before you begin with the application process you need to ensure the front grille is clean of any acrylic pen or dirt. We recommend you use an alcohol spray and cloth or jet wash.



Step 2. Once your grille is clean, lay out your letters in front of you with the sticky tape facing upward in the correct order.

Please visit the links to **ensure the correct application process is followed** and that your letters will stick. **We cannot accept responsibility for incorrect application.**

[https://www.selfadhesive.co.uk/media/wysiwyg/VHB\\_Cleaning\\_priming.pdf](https://www.selfadhesive.co.uk/media/wysiwyg/VHB_Cleaning_priming.pdf)

<https://www.selfadhesive.co.uk/media/wysiwyg/5952F-UK.pdf>

Step 3. Begin by peeling the top layer of the 3M tape off each piece, but only do this for one letter at a time. If it is relatively cold out, try and warm up the tape by placing the letter in-between your hands to ensure it sticks well.

Step 4. Once all the top layers have been removed, the letter is ready for installation. Line up the letter to the outline on the grille and press the letter on once you're satisfied with its placement. Apply pressure to the letter for around 15 seconds.

Step 5. To guarantee it's stuck on, apply pressure with your finger around the letter until it feels secure. Make sure you follow steps 3-5 for the remaining letters.

Step 6. Enjoy your new front grille!

Thank you for your purchase with us!

