Abarth Chrome Replacement Kit

INSTRUCTIONS

Before Installation:

Please ensure you have some sort of trim removal tool whether that's a flathead screwdriver with some tape over the head, or even a pair of tweezers.



Step 1.

Remove the chrome rings using a trim tool, screwdriver or even a pair of tweezers and hook the inside of the ring and pull. The chrome ring should just pop off!



Step 2.

Once the chrome ring has been removed, take your new chrome ring and line up the prongs. Two big at the top, one small at the bottom.

<u>Step 3.</u>

Apply pressure to the ring until you hear the 'click'. The chrome ring should then be clipped in and secure.

Step 4.

Continue these 3 steps on the remaining chrome rings and admire your new dashboard!

Thank you for your purchase with us!







